



PRODUCT SPECIFICATION

INDIVIDUALLY PACKED AUTOCLAVABLE GOGGLES NON-STERILE



PRODUCT INFORMATION

PRODUCT DESCRIPTION

Specifically designed for use in Cleanroom Environments this CE and UKCA accredited goggle can withstand multiple autoclave sterilisation without degradation. The lightweight design gives a wide angle of view and increased wearer comfort as it is coupled with a wide easily adjustable strap.

PRODUCT FEATURES

EN 166 3 4 BT Compliant.
CE and UKCA Marked.
Supplied in a Non-Sterile condition but packed in an Autoclave bag ready for immediate sterilisation.
40 process lifespan for goggles without significant fogging.
Lightweight, supplied with adjustable head strap and easy to use snap-on clip.
Indirect ventilation to top of goggle to prevent fogging and protect from splashes.
Compatible with most prescription glasses.

PACKAGING

Supplied individually packed in an outer Polyethylene pouch with easy tear and an inner autoclave ready bag.

USER STERILISATION

Use only de-ionised or distilled water when autoclaving, autoclave at 121°C (250°F) for a minimum of 15 minutes.

When packing for autoclaving please follow our recommended procedure to prevent staining or streaking.

QUALITY ASSURANCE

Product supplied under BS EN ISO 9001 registered systems.

STORAGE CONDITIONS

Store in cool, well ventilated area.

SHELF LIFE

Goggle should be autoclaved within 3 years of delivery if using the as supplied autoclave ready bag.

PRODUCT INFORMATION

Lens: Impact rated polycarbonate
Frame: Lightweight thermoplastic rubber
Strap: Silicone
Snap on Clip: Polycarbonate

ORDERING/PACKING INFORMATION

Non-Sterile Code	Sterile Code	Description	Size	Pack Qty	Case Qty	Case Dimensions	Weight
ONACL0112		Individually Packed Autoclavable Goggles Non-Sterile	One Size	Each	12	430 x 380 x 150mm	2.25kg